



The Bromic Butane Pencil Torch will melt solder, silver/gold solder, small brazing rods, glass tubing as well as many other materials such as gold, silver, tin and aluminum. It is easy to maintain, refill or use and is designed to hold just enough gas to do the job safely.

PLEASE READ FOLLOWING INSTRUCTIONS BEFORE USE. How To Refill

Make sure that the torch is extinguished before refilling
Follow directions on refill cannister

3. Complete fill takes roughly 10 seconds. Please allow a few minutes for gas to stabilize

How To Light

Turn the control valve counter clockwise until a small amount of gas can be heard escaping through the burner and ignite.



CAUTION: The control valve is fitted with "O" rings to prevent leakage of gas at the control valve. The control valve should not be opened beyond a point where "O" ring just becomes visibe.

Aside from the Butane Pencil Torch, Bromic Plumbing & Gas offer a comprehensive range of soldering and welding tools and acccessories. To view our full range visit **www.bromicplumbing.com.au**.

WARNING: Never expose to direct sunlight or temperatures above 50°C. Keep out of reach of children. Read all package warnings and observe all instructions.

DANGER: After proper fuel filling, the Butane Pencil Torch will contain flammable gas under pressure. Failure to comply with these warnings and instructions may result in an explosion or fire that may cause property damage, personal injury or death.

BROMIC Pty Ltd 10 Phiney Place, Ingleburn, NSW 2565 Australia Phone: 1300 276 642 Fax: (02) 9748 4289 Email: plumbing@bromic.com.au MADE IN TAIWAN CODE: 1811630



BROMIC.COM.AU